

Original Instructions

Installation, Operation & Maintenance Manual

ISOLOK SAK Sampler Point Samplers

S-AS-IOM-00422-2 10-22



COMPANY WITH
QUALITY SYSTEM
CERTIFIED BY DNV GL
= ISO 9001 =

 SENTRY



Do not install, maintain, or operate this equipment without reading, understanding, and following the appropriate Sentry Equipment Corp instructions. Otherwise, injury, damage, or both may result.

Copyright

© 2022 by Sentry Equipment Corp. All rights reserved. All product and company names are property of their respective owners. This document contains proprietary information. No part of this document may be photocopied or reproduced without the prior written consent of Sentry Equipment Corp.

Limit of Liability

Sentry Equipment Corp, its employees, agents, and the authors and contributors to this document specifically disclaim all liabilities and warranties, express or implied (including warranties of merchantability and fitness for a particular purpose), for the accuracy, currency, completeness, and/or reliability of the information contained herein and/or for the fitness for any particular use and/or for the performance of any material and/or equipment selected in whole or part with the user of/or in reliance upon information contained herein. Selection of materials and/or equipment is at the sole risk of the user of this publication.

Note

The information contained in this document is subject to change without notice.

Table of Contents

Safety Information	4
General Safety Precautions	5
General Description	6
Installation	6
Selection of Installation Location	6
Line Adapter Mounting (if provided)	7
Sampler Mounting	7
Controller (if provided)	7
Service Connections	7
Operation	8
Sample Containers	8
Controller (if provided)	8
Venting	11
Sample Collection Containers	11
Maintenance	11
Sampler Cleaning	11
Sampler Removal	12
Plunger Seal Disassembly	12
Plunger Seal Reassembly	13
Piston Seal Disassembly	13
Troubleshooting	15
Standard Warranty	16
Customer Support	16

Safety Information

Please read the entire manual before attempting to unpack, set up, or operate this product. Pay careful attention to all Warnings, Cautions, and Notes. Failure to do so could result in serious personal injury and/or equipment damage.

Use of Hazard Information

If multiple hazards exist, the signal word corresponding to the greatest hazard shall be used.

Definitions

DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to personal injury.

NOTE

Information that requires special emphasis.

TIP

Alternate techniques or clarifying information.

SHALL: This word is understood to be mandatory.

SHOULD: This word is understood to be advisory.

General Safety Precautions

Product Selection, Installation, and Use

WARNING

Improper selection, installation, or use can cause personal injury or property damage. It is solely the responsibility of users, through their own analysis and testing, to select products suitable for their specific application requirements, ensure they are properly maintained, and limit their use to their intended purpose.

Follow proper local, state, and federal regulations for proper installation and operational requirements.

Always use caution and common sense when working with any chemical. Read the product label and Material Safety Data Sheets (MSDS) carefully and follow the instructions exactly.

Potential Equipment Hazards

WARNING

Hot surfaces! This equipment may have very hot surfaces. If an operator contacts a hot surface, injury may occur. Use protective clothing to prevent injury. If other equipment comes in contact with a hot surface, damage to the equipment may occur. Ensure the area around this equipment is kept clear to prevent damage from occurring.

High pressures! This equipment may contain fluids at very high pressures. Prior to installing, removing or maintaining this equipment, ensure that the equipment is isolated from all connecting piping, the equipment is depressurized, the contents have been drained, and the equipment is cool.

Moving parts! This equipment may contain moving parts. All drive guards and doors must be secured in place when this machine is being operated.

WARNING

Equipment rated TX. Equipment maximum surface temperature depends on operating conditions. Ensure maximum surface temperature shall stay below ignition temperature of dust or gas atmosphere where it is installed based on process conditions. Failure to comply could result in an explosion, causing serious injury or death to personnel and damage to equipment.

If the sampler is mounted directly to a non-electrically conductive surface, sampler shall be bonded to a grounding electrode. Failure to comply could result in sparking, which could lead to an explosion, causing harm to personnel and equipment.

If the sample container is removed from the sampler, do not insert any body part or other item into the sample discharge port. Crushing will occur.

NOTICE

To ensure proper sampler operation, be sure the sampler is installed in a pipe large enough for the sampler plunger to extend without impacting the pipe. Failure to comply will result in equipment damage and poor sample quality.

CAUTION

Sampler may require a two-person lift. Please refer to the General Arrangement drawing for weight and dimensional information.

General Description

WARNING

Read these instructions completely before proceeding to assemble, install or operate this machine. This machine should be installed, operated and serviced by qualified individuals. All drive guards and doors must be secured in place when this machine is being operated. Follow proper local, state and federal regulations for proper installation and operational requirements.

The Sentry® ISOLOK® SAK automatic point sampler provides a simple, reliable means of collecting representative samples of flowable powders, flakes or granules. Materials such as salt, cement, fertilizer, alumina, gypsum and food products are sampled from process streams at atmospheric pressure. An auxiliary top body port enables air ejection of non-free-flowing materials.

Each sampler cycle consists of a plunger extension and a plunger retraction. During plunger extension, the volume of the annulus is filled with a sample of the process material. The plunger then is retracted into the body of the sampler, thereby capturing a volume of sample. This sample is then deposited into a sample collection container.

The ISOLOK SAK automatic fixed volume sampler is pneumatically operated. Pressurized air (or other gas) is used to provide the force to extend and retract the plunger. When in the retracted position, air or other inert gas may be used to assist the displacement of the sample material from the plunger annulus.

The ATEX Temperature Class rating is dependent upon process fluid temperature. Reference the following chart:

TX	maximum temperature
T2	572°F (300°C)
T3	392°F (200°C)
T4	275°F (135°C)
T5	212°F (100°C)
T6	185°F (85°C)

ATEX Ratings:

Ex h IIB T6...T2 Gb
Ex h IIIC T83°C...T300°C Db
-20°C ≤ Ta ≤ +65°C

NOTE

The working pressure of the air cylinder is 120 psig with a max cycle rate of 15 cycles/min on a continuous duty cycle. Additionally, actuating gas needs to be a non-combustible neutral gas and the working temperature must be between -4°F to 149°F (-20°C to 65°C).

NOTE

Figures in this manual may differ from actual purchased equipment. Please refer to the drawings in the appendices of this document.

Installation

Selection of Installation Location

Select a location to install the sampler where the material in the process stream is well mixed. Location of the sampler and controller is very important for accurate sampling results. They should be as close together as practical, within sight of each other, and protected from weather, traffic damage and normal work activities in the area.

When selecting a sampler location, ensure the sample collection container will clear vertical lines (or other obstructions) when mounted onto the sampler. The sampler can be used on a bin, slide, housing or drop chute running horizontally, vertically or at an angle, but the preferred position is with the axis of the sampler horizontal. However, the sampler body axis can be below horizontal depending on the material being sampled and its flow characteristics..

Line Adapter Mounting (if provided)

1. Reference the accompanying drawing to determine which line adapter had been provided.
 - a. SADDLE SHAPE line adapters are machine cut to fit the OD of sampler diameter process pipes.
 - b. PLUG SHAPE line adapters are installed through the wall of larger diameter pipes or sides of tanks.
2. After selecting a location and verifying the sampler orientation, cut a hole in the process line (or tank) according to the shape of the line adapter. Exact size to cut is shown on the accompanying drawings
3. Protect bore and face of adapter from weld spatter.
4. Tack weld adapter in position. Again, check orientation and position before continuing to weld.

NOTICE

Use industry code procedures to protect adapter from distortion. Major distortion cannot be corrected and will prevent installation of sampler.

Sampler Mounting

⚠ CAUTION

Sampler may require a two-person lift. Please refer to the General Arrangement drawing for weight and dimensional information.

1. ISOLOK samplers are designed to mount to a line adapter that is welded or otherwise attached to a process line.
2. PLUNGER CLEARANCE. Ensure that adequate clear space exists ahead of nose of sampler to allow for full plunger movement.
3. Check orientation of sampler and line mounting adapter, and ensure that axis of sampler is mounted as shown on the accompanying general arrangement drawing.

Controller (if provided)

1. Make connections as shown on the accompanying drawings.

Service Connections

1. Make air line connections as shown on the accompanying drawings.
2. For most installations, the sampler requires compressed air at normal flow capacity of 2 standard cubic feet per minute (SCFM) at normal regulated pressures between 30 psig (2.1 barg) and 80 psig (5.5 barg).
3. At 80 psig (5.5 barg), air consumption is approximately 0.023 SCF per sampler cycle for 1-1/2 in. cylinders, and 0.063 SCF per sampler cycle for 2-3/8 in. cylinders.

4. AIR LINES. Connect two air outlet ports on controller to sampler air fittings P5 on head and P6 on rear of cylinder using 1/4 in OD air lines. Use no more line than is necessary.
5. An adjustable restrictor (flow-control valve) should be used to control exhaust air flow from the air cylinder. Consult Sentry Equipment Corp if not furnished as part of the operating controller system.
6. Connect lines so that sampler dwells in retracted position while in between cycles or when off.
7. Check for proper connection of air lines by extending the sampler plunger using the "HAND" or "GRAB" option of the controller.
8. AIR EJECT (Optional). If an "air eject" function has been selected, the top port (P2) of the sampler body can be equipped with a compression style fitting. Connect this port to source of eject air (or other gas) at control using 1/4 in OD tubing. Samplers equipped with an air eject function MUST have suitable vent in bottle adapter to allow for exhaust of eject air. DO NOT CLOSE VENT PORT. Ensure any potentially hazardous fumes or product are conducted to a safe area.

Operation

DANGER

Dangerous gas! The gases being emitted from the bottle vent may be hazardous and toxic upon exposure. The vent line should be directed to a charcoal canister, flare or other sub atmospheric region for collection and treatment of sample vapors.

Sample Containers

1. Sample collection containers always should be clean and completely dry before being used. Containers (bottles) of polypropylene most often are utilized.
2. SCREW MOUNT CONTAINERS. Standard sampler body is provided with a threaded discharge port. Adapters to fit threaded sample collection bottles are available from Sentry Equipment Corp. These adapters have a suitable threaded port and mount onto discharge port.
3. SEPARATE CONTAINERS. Suitable piping connections for metal or plastic components can be arranged to conduct sample portions to a separate container. Whenever such piping is installed, avoid long runs with multiple fittings, joints or other areas where solids or crystals could build up and block flow.

NOTE

IMPORTANT. Select sample container size that will not be filled completely even during longest sampling times. Use care when setting a cycle rate that may nearly fill a container.

WARNING

Always ensure control is OFF before mounting or exchanging sample containers.

Controller (if provided)

ISOLOK samplers require an operating controller which determines the time interval between cycles, speed of the plunger and dwell in product stream. Filtered, compressed air or gas is provided from controller to sampler air cylinder

for operation.

Operation can be manual-pneumatic, electric-pneumatic, all-pneumatic, etc. A few are described:

- Manual-Pneumatic Control includes a filter, regulator, gauge, and lever operated four-way air valve with speed controls and mounting bracket. The lever is depressed to extend the plunger and held approximately two seconds. The lever release retracts the plunger. A stainless steel enclosure with locking provision is optional.
- Electric-Pneumatic Control includes an electric power supply for the timer and solenoid operation with separate pneumatics. Time-based units include EXTEND-RETRACT adjustable plug-in timers to control time intervals and optional special time delay functions. Flow proportional or remote contact controls operate from the user's flow meter or pulse generating device and usually include an adjustable counter. NEMA 4 or NEMA 7 enclosure models are available.
- All-Pneumatic Control is suitable for explosion hazard-rated areas where compressed air is available for sampler operation or for areas where electric power supply is not available.

General Specifications

In most cases, an automatic electric sampler cycle controller requires an 115VAC power supply. IN ALL CASES controls require a suitable ground and means to disconnect the electrical supply.

When connecting a contact closure or pulse input from the flow meter to the controller, using shielded cable is recommended if the run is more than 10 feet or if the conduit contains leads of higher voltage.

The controller location should be within sight of the sampler and require connecting air lines to the sampler of no more than 30 feet.

Connect a compressed air supply line to the sampler operating controller of nominal flow capacity in the range of 2 SCFM at 80 psig (5.5 barg) to 120 psig (8.3 barg). Dry, oil-free air gives best operation with minimum maintenance. Adequate use of air filters is recommended. Minimum pressure setting of 30 psig (2.1 barg) is required. The maximum pressure setting should be less than the incoming air supply to ensure steady, regulated pressure on the sampler.

Automatic Cycle Rate

Select a cycle rate on an adjustable delay timer that will provide an adequate sample composite for the container in use. DO NOT overfill the container. Sample delivery is charted for samplers with 16cc and 18cc liquid volumetric displacement per cycle. A partial chart is shown on the following page. Cycle rate is a combination of the time needed to fully extend the plunger into the product line, then completely retract and discharge the sample collected.

↪ NOTE

The plunger should remain extended into the process flow for the shortest amount of time possible.

To convert cubic centimeters to fluid ounces, multiply by .0338. There are approximately 30cc (29.5735) to one fluid ounce, 128 fluid ounces to one U.S. gallon.

$$\text{*CYCLE TIME} = \frac{\text{CC PER CYCLE} \times \text{TOTAL SAMPLING TIME (SEC)}}{\text{TOTAL SAMPLE (CC)}}$$

$$\text{* CYCLE TIME (SEC)} = \text{EXTEND TIME} + \text{RETRACT TIME}$$

Specialized controls are available on request to suit various requirements.

total sample (cc) at 16 cc per cycle						
	total sampling time					
cycle time*	5 min	10 min	30 min	1 hr	8 hr	24 hr
5 sec	960	1920	5760	11520	92160	276480
10 sec	480	960	2880	5760	46080	138240
15 sec	320	640	1920	3840	30720	92160
20 sec	240	480	1440	2880	23040	69120
30 sec	160	320	960	1920	15360	46080
60 sec	80	160	480	960	7680	23040
120 sec	32	80	240	480	3840	11520
300 sec	16	32	96	192	1536	4608
480 sec	--	16	48	112	960	2880
600 sec.	--	16	48	96	768	2304

total sample (cc) at 18 cc per cycle						
	total sampling time					
cycle time*	5 min	10 min	30 min	1 hr	8 hr	24 hr
5 sec	1080	2160	6480	12960	103680	311040
10 sec	540	1080	3240	6480	51840	155520
15 sec	360	720	2160	4320	34560	103680
20 sec	270	540	1620	3240	25920	77760
30 sec	180	360	1080	2160	17280	51840
60 sec	90	180	540	1080	8640	25920
120 sec	36	90	270	540	4320	12960
300 sec	18	36	108	216	1728	5184
480 sec	--	18	54	126	1080	3240
600 sec.	--	18	54	108	864	2592

The sampler design precludes marking each component of the sampler with a part or serial number. We recommend the user uniquely identify each sampler and controller. Equipment identification becomes invaluable when operating more than one sampling instrument serviced through a central maintenance facility. Identification tags can be provided from Sentry Equipment in laminated plastic or metal to be attached to the sampler or controller. Price of the tags is available upon request.

Sampling should be performed only when the product is moving. Sampling from stagnant (stationary) product can bias the sample. Starting and stopping the sampling system can be done manually or by interlocking to a pump or valve. Special controls are available for use with flow meters or for remote computer operation.

CAUTION

Product collected with each sampler plunger cycle drains from the discharge port (P1) of the sampler into the container. However, there is always some clingage to wetted parts. Those collecting samples should be instructed in proper techniques and care when handling containers. If required, users should wear protective equipment such as gloves, masks or other clothing at all times when operating sampling equipment where exposure to the sampled product could be hazardous.

Venting

Samplers used on pressurized lines – where expansion of entrained gas, air, steam or fumes could cause a pressure rise in the sample bottle – require adequate venting.

1. Venting may be provided by a port in the bottle adapter or body top port of the sampling instrument. Ensure any potentially hazardous fumes or product are conducted to a safe area. Periodically check to ensure the vents are open and unclogged.
2. Vent or drain ports always should be located to avoid accidental exposure of an operator to hazardous or hot material. Where evaporation or vapor loss through a vent is undesirable, the vent should be equipped with a proper control.
3. Contact Sentry Equipment Corp for clarification of any questions on venting of the sampler system.

Sample Collection Containers

WARNING

Always ensure controller is OFF before mounting or exchanging sample containers.

The sampler has been provided with one of a variety of sample collection container connections. See the accompanying drawing to identify which has been provided.

1. Sample collection containers always should be clean and completely dry before being used. Containers (bottles) of polypropylene most often are utilized.
2. SCREW MOUNT CONTAINERS. These adapters have a suitable threaded port and mount onto a discharge port.
3. SEPARATE CONTAINERS. Suitable piping connections for metal or plastic components can be arranged to conduct sample portions to a separate container. Whenever such piping is installed, avoid long runs with multiple fittings, joints or other areas where solids or crystals could build up and block flow.

Maintenance

WARNING

Sampler must not be disassembled or removed from line until line is free of product, is at atmospheric pressure, all components are at safe temperature, and all services have been shut off.

Sampler Cleaning

1. Operating an accurate and valid sampling installation is critically dependent on effective cleaning procedures. ISOLOK samplers incorporate materials, finishes and design to allow effective cleaning of seals, ports, vents and interior body cavities.
2. Whenever a sampler is cleaned, it should be lubricated and inspected for wear and damage that can affect its continued successful operation. The sampler periodically should be checked for proper operation and to ensure that any wear is detected for preventive maintenance.

3. On continuous duty installations, the sampler should be checked once a day for proper operation. On all installations, a definite schedule of inspection should be established to ensure safe and accurate sampling operation. ISOLOK samplers initially must be installed and periodically inspected to ensure all connections, clamps and fasteners are firmly tightened. Failure to keep screws or connections properly secured could result in leakage or damage.
4. Do not weld, machine or otherwise modify the sampler or control in any manner. Consult Sentry Equipment Corp before undertaking any changes. Follow your plant safety procedures whenever maintenance or inspection is required on this equipment.
5. We recommend that service records be maintained on sampling equipment. Data should include:
 - a. Sampler: Record date of installation, date of seal replacement, which seals were replaced and the condition of used seals, and the reason they were replaced. Accurate records will assist in determining seal life or if abnormal operating conditions exist. Contact Sentry Equipment Corp if unusual wear or chemical attack to the seals or the metal parts of the sampler occurs.
 - b. Controller: Record the date of installation, the date of timer or air valve replacement, items replaced and the condition of used parts. Indicate the reason they were replaced. Frequent replacement of timers may indicate an issue with the controller operating environment. Impurities in the air supply source may cause premature failure of pneumatic components.

Sampler Removal

WARNING

Sampler must not be disassembled or removed from line until line is free of product, is at atmospheric pressure, all components are at safe temperature, and all services have been shut off.

Refer to the included general arrangement and assembly drawings for removal information. All service to the sampler should be performed with it removed from the process line.

Plunger Seal Disassembly

WARNING

Sampler must not be disassembled or removed from line until line is free of product, is at atmospheric pressure, all components are at safe temperature, and all services have been shut off.

If preliminary inspection of the sampler plunger or persistent leakage indicates replacement of the plunger seals or o-rings, remove the complete sampler from the line adapter and proceed as follows.

1. Carefully apply compressed air to the rear cylinder port, fully extending the plunger. The plunger seals now can be accessed for inspection without further disassembly.
2. Remove the clamp at the rear of the body or unbolt the air cylinder from the body and withdraw the cylinder and plunger from the body.

CAUTION

Decompression of seals may occur as the plunger is removed. Protect personnel from exposure to sample material trapped between plunger seals.

3. Unscrew the plunger from the piston rod using the wrench flats provided. Metal parts slide off the spindle. Observe the position of the parts as removed and set aside carefully, taking care not to lose any small parts.
4. If any seal is worn flat on the outside diameter, torn, scored or experiencing chemical degradation, remove the seals from the carriers and sleeve.
5. Check to ensure the spindle has not been bent and all parts are smooth and free of score marks. Scored or damaged parts should be repaired or replaced.

NOTICE

Do not nick or scratch seal seats.

Plunger Seal Reassembly

Reassembly is done in reverse order of disassembly procedure. Always work with the sampler group drawing as a guide. The following techniques will be helpful in reassembling seals and components of plunger module.

1. Wipe and clean seal seats of metal parts. Always replace the plunger seals as a complete set.
2. Wipe seals with a light film of process compatible lubricant as an aid in assembly, if required.

NOTICE

Do not use petroleum-based grease, oil or similar hydrocarbon lubricants on the EPDM plunger seals; they will swell the rubber material.

3. Press seals onto carriers. Use careful, steady hand pressure to avoid seal damage.
4. Seals will stretch more easily if they are warmed on a hot plate or in hot water. Also, lubricate seals before stretching them over the plunger. (Use the optional seal loading tool for ease of seal assembly. Contact Sentry Equipment Corp for more information.)
5. Starting from spindle head end, install components in order and orientation as shown on the sampler group drawing.
6. Screw the plunger assembly carefully into the piston rod by hand. Using the wrench flats provided, torque the spindle to torque value provided on the accompanying drawing. Check the concentricity of the assembled plunger module to ensure it is straight. (Use optional plunger seal alignment sleeve to align the plunger parts before tightening the spindle screws. Contact Sentry Equipment Corp for more information).
7. When the plunger module is assembled with seals, test interference fit of the plunger through the body bore by pushing the plunger back and forth. Reinstall the cylinder and plunger into the body module and clamp securely.

Piston Seal Disassembly

WARNING

Sampler must not be disassembled or removed from line until line is free of product, is at atmospheric pressure, all components are at safe temperature, and all services have been shut off.

1. Remove the clamp at the rear of the sampler body or unbolt the air cylinder from the body.
2. Inspect the bore of the barrel for scoring or wear. Wipe out with a dry, non-abrasive cloth.

NOTICE

Do not use solvents. A heavily scored barrel should be replaced.

3. Inspect and replace the piston seals and rod seals if needed.
4. Reassemble the plunger to the piston rod and torque to 12 ft. lbs.
5. Reassemble the barrel to the head. Ensure the o-ring seal is in place and tighten the screws securely.

Troubleshooting

symptom	possible problem(s)	remedy
Sampler leaks product or air out of bottom ports	<ul style="list-style-type: none"> ▪ Worn seals ▪ Incorrect installation ▪ Other worn parts 	<ul style="list-style-type: none"> ▪ Thorough inspection is required ▪ Replace worn seals ▪ Check any recently replaced seals against drawings for correct installation ▪ Replace other worn sampler parts: Body, head, barrel or plunger
Sampler leaks product at pipe connection	<ul style="list-style-type: none"> ▪ Installation misaligned ▪ Fastener, clamp/gasket or seals issue 	<ul style="list-style-type: none"> ▪ Check installation for misalignment ▪ If the installation is threaded, replace locknut fastener and add commercial grade Teflon tape when reinstalling ▪ If the installation is tri-clamp or instrument hub, check the clamp/gasket (TC) or o-rings/fasteners (IH) attaching the sampler to the line adapter ▪ Replace seals if they are damaged or show signs of chemical attack
Sample discharge is decreasing	<ul style="list-style-type: none"> ▪ Buildup in sample spool cavity or sampler nose 	<ul style="list-style-type: none"> ▪ Check sample spool cavity for buildup; if present, add flush or air eject provision to sampler body ▪ Check sampler nose for buildup; if present on nose or pipe wall interior, remove the body from the line frequently and clean it using plant procedures
Sampler will not operate	<ul style="list-style-type: none"> ▪ Issues with power source and/or air connections 	<ul style="list-style-type: none"> ▪ Check power source and air connections; connect as required ▪ Check air lines for proper connection, as plunger must dwell retracted; air lines connected backwards will cause sampler to dwell (pause) extended into the process line ▪ Check for air bind; depending on the density of the product sampled, this sometimes can be resolved by opening a top port on the sampler ▪ Check sampler operating air pressure and process line pressures; operating air pressure must be sufficient to move the plunger against process pressure. Issue may be resolved by increasing or decreasing air to sampler or relocating sampler.
Controller does not operate	<ul style="list-style-type: none"> ▪ Issues with pneumatic and/or electric power source 	<ul style="list-style-type: none"> ▪ Verify correct 115V or other specified power to controller ▪ If using a remote contact unit, check the output signal to the controller from the flow meter; check purchase records, and if an incorrect output signal was specified, contact Sentry Equipment ▪ Secure a qualified technician to run a complete operating check of timing circuits, remote contact inputs and/or counter inputs that sequence the electric or pneumatic power valve

Standard Warranty

Sentry Equipment Corp (“Seller”) warrants products manufactured by it and supplied hereunder (“Products”) to be free from defects in workmanship and, to the extent materials are selected by Seller, to be free from defects in materials, in each case for a period as defined in the table below:

Product Line	Product Category	Warranty Period
Sentry®	1. Automatic Sampling 2. Corrosion Monitoring 3. Manual Sampling 4. Sample Conditioning 5. Sampling & Analysis Systems 6. Replacement Parts (without expiration dates)	Eighteen months from date of shipment or twelve months from startup, whichever occurs first
Waters Equipment	1. Sampling & Analysis Systems 2. Replacement Parts (without expiration dates)	Twelve months from date of shipment

To view the full warranty, go to www.sentry-equip.com/warranty.

Customer Support

With proven sampling expertise since 1924, Sentry products and services provide business operations the critical insights to optimize process control and product quality. We deliver true representative sampling and analysis techniques to customers around the globe, empowering them to accurately monitor and measure processes for improved production efficiency, output, and safety. Standing behind our commitments, we are determined to tackle any application, anywhere.

We know that running an efficient operation isn’t easy. It requires thorough, careful analysis of controlled, real-time data achieved through reliable, accurate, and repeatable process monitoring, and measuring. By effectively conditioning, sampling, and measuring gas, liquid, slurry, powder, solids, steam, or water within their production environments, our customers obtain the critical insights they need to control and optimize their processes.

Yet, controlling your processes also means reliable customer support throughout the life cycle of your equipment.

- Customer Service—General information, warranty claims, order management.
- Installation Service—For systems that require specialized expertise upon installation.
- Technical Support—Troubleshooting, training, and technical manuals.
- Field Service & Retrofits—When a problem needs immediate attention.
- Replacements Parts & Consumables—Order your replacement parts and consumables.
- Sentry ProShield Services—Select from four ProShield Guardian service plans providing different levels of support to protect your large system investments with regularly scheduled maintenance.

To learn more, go to www.sentry-equip.com/support.

EC DECLARATION OF CONFORMITY

(MSD 2006/42/EC, Annex II, 1, A)

Manufacturer's Name: Sentry Equipment Corp

Manufacturer's Address: 966 Blue Ribbon Circle North
Oconomowoc, WI 53066
Tel: 262-567-7256 Fax: 262-567-4523
Email: sales@sentry-equip.com

European Authorized Representative's Name: Obelis S.A

European Authorized Representative's Address:
Boulevard Général Wahis 53, B-1030 Brussels,
BELGIUM.
Tel: 32 (0) 2 732 5954 Fax: 32 (0) 2 732 60 03

Person authorized to compile the Technical File, established in the Community:
Obelis S.A. (see address above)

Description of the machinery: ISOLOK Sampler

ATEX Classification:



The maximum surface temperature of this device is dependent on and may equal process fluid temperature. The process fluid temperature must never exceed the rating of the device. Reference EN13463-1 Section 14.2 (g).

Directive(s) Complied with: European Council Directive on the Safety of Machine 2006/42/EC
ATEX 94/9/EC

European Harmonized Standards to which Conformity is Declared:


- | | |
|------------------------|---|
| EN-13463-1:2009 | Non-electrical equipment for use in potentially explosive atmospheres. Basic method and requirements. |
| EN-12100-1:2003 | Safety of machinery – Basic concepts, general principles for design. Basic terminology, methodology |
| EN-12100-2:2003 | Safety of machinery – Basic concepts, general principles for design. Technical Principles |

We, the undersigned hereby, declare that the machinery specified above fulfills all the relevant provisions of the European Council Directive 2006/42/EC

Technical File Lodged:

SIRA 10XT346
Sira Test & Certification Ltd.
Rake Lane
Eccleston, Chester
CH4 9JN, UK

Manufacturer: Sentry Equipment Corp

Signature:  **Date:** December 8, 2010

Full Name: Stanley Filipak
Position: Quality Manager
Place: Oconomowoc, WI

This page is intentionally left blank.

This page is intentionally left blank.

Serving customers
in more than 50 countries
across six continents worldwide.



[sentry-equip.com](https://www.sentry-equip.com)

966 Blue Ribbon Circle North, Oconomowoc, WI 53066 U.S.A. | +1-262-567-7256 | support@sentry-equip.com